

Note

Thank you very much for purchasing this Standard Horizon product. Local Channel assignments are not set in the factory. Before using the transceiver for the first time, please set the local channel assignment as below.

To do this, follow the procedure below:

1. Please select your local region as appropriate (see table).

Region	Display	Additional Channel
INTERNATIONAL	INTL	—
UNITED KINGDOM	UK	M: 157.850 MHz (TX/RX) M2: 161.425 MHz (TX/RX)
BELGIUM	BEL	CH31: 157.550 MHz (TX) / 162.150 MHz (RX)
NETHERLANDS	NL	CH31: 157.550 MHz (TX) / 162.150 MHz (RX) CH37: 157.850 MHz (TX/RX)
SWEDEN	SW	L1: 155.500 MHz (TX/RX) L2: 155.525 MHz (TX/RX) L3: 155.650 MHz (TX/RX) F1: 155.625 MHz (TX/RX) F2: 155.775 MHz (TX/RX) F3: 155.825 MHz (TX/RX)
GERMANY	GRMN	—

2. Turn the transceiver ON.
The region selection message appears on the display.
3. Press the [NEXT] soft key.
4. Press the [▲] or [▼] key momentarily to select the desired region (see table above).
5. Press the [ENTER] soft key to store the selected setting.
A "SELECTED" will appear on the display.
6. Press the [OK] soft key to restart automatically.

The region setting was successfully completed.

Note: After a factory reset, any local channel assignments will be lost and this procedure will need to be repeated.



STANDARD HORIZON



E M 0 6 4 N 5 0 0

1811H-AC