



Got feedback from the manufacture of the dynamo.

The yellow cable is Neutral Point cable, voltage is 6V.

The red cable is Excitation End, it connects with the positive pole of storage battery.

The blue cable is charging indicator cable, should connect with the light of charging indicator.